



Adjustment software

DTM Collection and PACTware	240
VEGACONNECT	241



DTM Collection and PACTware

Open adjustment software with device description inclusive adjustment interface according to the FDT standard

Application area

In conjunction with an appropriate DTM, PACTware is the adjustment software for configuration, parameter adjustment, documentation and diagnostics. PACTware is available as a free of charge download and the program can be used on the PC for parameter adjustment and configuration of field devices and signal conditioning instruments. It supports instruments of different manufacturers.

Advantages

- License-free configuration tool for all communication-capable VEGA instruments
- Unique, standardised interface according to FDT specification
- Standard version for adjustment of all parameters of an instrument incl. project storage and project documentation
- Free-of-charge download of this standard version also via www.vega.com (Home » Downloads » Software)
- Full version with extended functions, for example Multiviewer, tank calculation and storing of echo curves

Function

VEGA DTMs are created according to the FDT Style Guide. The wide-spread technology is manufacturer and Fieldbus-independent. FDT/DTM supports the complete function range of the field instruments and simplifies the setup of an instrument. The project overview and the adjusted values of the individual instruments can be simply stored and printed with PACTware.

Recommended operating systems

- Windows XP from SP2 (32 bit)
- Windows Vista (32 or 64 bit)
- Windows 7 (32 or 64 bit)

Other system requirements

- 1 GHz processor or higher
- 1 GB RAM or higher
- 1 GB free memory
- Internet Explorer 6.0 or higher
- Microsoft .NET Framework 2.0
- RS232/USB/Ethernet interface
- Graphic resolution 1024 x 768 or higher



Software

- SV** Standard version incl. project storage, documentation
- FV** Full version with multiviewer and tank calculation





VEGACONNECT

Interface adapter between PC and communication-capable VEGA instruments

Advantages

- For use on PCs with USB interface
- Adjustment via DTM and adjustment program PACTware
- Suitable for connection to plics® sensors
- Incl. connection box with different connection cables and adapters



CONNECT.CXA4



